

F.No.2_HELICOPTER SPARE PARTS

AVAILABLE FOR SALE!!!!

RUSSIAN HELICOPTER SPARE PARTS - LOCATION: U. A. E.

Swash plate	Windscreen electric actuator	Service fuel tank	Transformer
Main rotor hub	Primary Converter	Fuel tanks	Automatic pressure
Vibration damper	The regulator	Automatic pump relief valve	Automatic switching
Tail rotor gearbox	Unit	Valve emergency power off	Radio altimeter
Intermediate gearbox	Lamp signal beacon	Gear pump	Radio altimeter
Tail shaft	Red glass for MSL-3-2s	Centrifugal pump	Voice recorder
The mounting frame of the main gearbox	Headlight	Electrically-driven centrifugal pump	The reproduction unit
Main gearbox	Electromagnet	Pump alcohol	Radio station
Engine (APU)	Micro switch	Electrically-driven centrifugal pump	Radio station
Fan	Resistance remote	Fire extinguisher	Cone top
Fan drive universal joint shaft	Electronic regulator of the engine	Pressure reducing valve	Cone bottom
Tail rotor blade	Ice detector	Pneumatic control unit (accelerator reducing)	Nut
Nose landing gear wheel levered shock strut	Erecting cut-out switch	Chain, 67 links	Finger VSH
Tail bumper shock absorber	Electronic unit	Crane electromagnetic	Glass
Section dustproof device (L & R)	Electromechanism	Filter element	Spring
Blister (L & R)	Brush	The horizon indicator	The reservoir is used
Glass blisters (L & R)	Giroagregat	Altimeter	Nut GS
Valve	Device matching	Airspeed indicator	Nut VSH
Management details	Lamp cabin	Engine pressure ratio indicator	Nut OSH
Main Rotor Brake	Filter	Electric three-pointer engine gage unit	Plate
Tyre	Altimeter	Electric fan	Pin
Brake (left)	Device navigation-landing	Electric turn indicator	Bolt
Disk	Unit conversion of the amount	Auto unit for engine start	Valve
Combination control hydraulic actuator	Control panel	Start control panel	Plug thrust of the blade
Compressor	The current collector	Generator	Leash
Cooler block (left and right)	Temperature regulator	The starter-generator	Pull
The diaphragm	Differential relay	Filter	Plug-alarm
Protected Service fuel tank	Potentiometric angle encoder is heat resistant	Solenoid brake	Case

CONTACTS AND COVERAGE WORLDWIDE:

Tel: +971 6 561 4546, Fax: +971 6 561 4542, P.O. Box: 121120, SAIF Zone, Sharjah, U.A.E.

E-mail: info@diversityholding.com, diversityholding@hotmail.com, Website: www.diversityholding.com

Skype: [diversityholding](https://www.skype.com/user/diversityholding) ABU DHABI & DUBAI: +971 50 956 3660

MANDATE: Skype: [bhjb.2013](https://www.skype.com/user/bhjb.2013) E-mail: bhjb.2013@hotmail.com ABU DHABI & DUBAI: +971 50 956 3380

WORLDWIDE COVERAGE:

Middle East & Gulf Countries, Asia, Australia, New Zealand, Europe, Eastern Europe, North, South & Central America, North, South, West, East & central Africa.